



The Montessori Room

Waldorf Rocker Assembly Instructions

Thank you for purchasing a Waldorf Rocker from us. We hope these instructions will help you assemble it quickly and properly. Please follow along so that it is safe to use. If at any point you have questions or seem to be missing a part, please contact us.

WARNING: As can be considered a climbing apparatus, please be aware that injuries can occur. Make sure that the rocker seems safe to use and is sturdy. Also make sure that while it is in use that you observe your child at all times while using it, and that the area is safe. Do not place it near hard edges such as fireplace mantles or stairs. A mat underneath would be advised. Contact us if the product seems unsafe or if there are any questions.

1. Please check that all parts were shipped. There should be:

- 2 large sides of the rocker
- 8 slats
- 36 flat head screws, 1.25" long, shiney bronze in colour
- One bottle of glue

2. You will need either a #2 robertson (square) screw driver or a drill with the #2 robertson bit. Be careful using a drill to put the screws in as you may over tighten them. If you do, they may strip the hole and spin in place. If this happens, they will not be securing the two pieces together. Also a mild damp rag or wet wipes may come in handy.

3. Setup the sides of the rocker on a large table or flat floor. A large flat area will be needed to make sure the sides are flat and parallel. All the slats are interchangeable, and can be used in any position.

4. Go slat by slat. Place a bead of glue in the groove. Do not put too much in it as it will squeeze out and make a mess. If glue squeezes out, use a mildly damp cloth or wet wipe. Match the corresponding number on the side with the number on the slat and push it into the groove. Use your drill or screwdriver to screw in the two screws. Again, please be careful if using a drill to put the screws in. It can either split the wood or strip the screw in the hole Work your way along one side.

5. After attaching all the slats to one side, the other side piece can be attached. Lay the side piece down with the grooves facing up. Place glue in all the grooves. Take the side with the attached pieces and attempt to fit the slats into their corresponding holes. You will need to wiggle the pieces and work your way along. After they all fit in, flip the whole assembly over. It is recommended to get help with this step, or some of the slats may pop out. After you flip it over, screw in the last screws.

6. After all the screws are in, check for any glue that may have squeezed out. Wipe up immediately before it dries. If all is well, you are done!